


Tools Required:

- 3mm hexagon socket wrench



Dimensions

- A:** 5-3/4"
B: 4"



Protection Class: N/A

Notice to Installer for 79 829:

1. See page 2 for specific product safety warnings.
2. The manufacturer is discharged from liability when damage is caused by improper use or installation.
3. Suitable for Bega performance floodlights:
84 215 • 84 330 • 84 661 • 84 216 • 84 663 • 84 662 • 84 660 • 84 217 • 84 332
84 120 • 84 208 • 84 209

79 829 - Lens Installation:

1. Using 3mm hexagon socket wrench, undo the (2) hexagon screws [Figure 1] and insert the shield into the groove in the floodlight housing.
2. Align the glare shield as needed and secure it in place by tightening (2) hexagon socket screws.

Figure 1:





Figure 2:



Maintenance

Clean regularly with solvent-free cleaner removing dirt and debris.

Do not use high pressure cleaners.

Accessories

Please refer to the appropriate accessory installation sheet for further instruction when applicable.

Replacement Parts

In the interest of product improvement, BEGA reserves the right to make technical changes without notice.

Product Safety Warnings:

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. SUITABLE FOR WET LOCATIONS.

MIN 90°C SUPPLY CONDUCTORS.

CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS. CONVIENT AUX EMPLACEMENTS MOUILLÉS.

LES FILS D'ALIMENTATION 90°C MIN.